

Assembly Instructions / a3 Holder



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw a tube into the half sphere
and a second tube into the first one.

3

Fix the black sphere.

4

Clip the three a3 frames on the tubes.

5

Place the black rubber ring on
the clip at the back of each frame.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

S p h e r i a[®]

