

Assembly Instructions /a3 Visuals Holder



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw one 0,50 m tube ø25 mm into the half sphere,
and a tube 1 m into the first one and then the 0,50 m tube.

3

Slide the spheres with the a3 kits on the tubes
at the desired height and oriented as you wish. Gently tighten.

4

Fix the black sphere.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

S p h e r i a[®]

