

Screw the stabilizer element under the half sphere with a flat screwdriver.

2

Screw one 0,50 m tube ø25 mm into the half sphere, and a tube 1 m into the first one and then the 0,50 m tube.

3

Slide the spheres with the a4 kits on the tubes at the desired height and oriented as you wish. Gently tighten.

4
Fix the black sphere.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



