

Assembly Instructions / Frame Holder



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw one tube $\varnothing 25$ mm into the half sphere,
and a tube $\varnothing 20$ mm into the first one.

3

Slide the sphere $\varnothing 25$ mm on the $\varnothing 25$ mm tube,
then slide the sphere $\varnothing 20$ mm on the $\varnothing 20$ mm tube.

4

Fix the black sphere.

5

Place the frame (not included) between the two spheres.
*Adjust it at the desired height
and gently tighten the two spheres holding the frame.*



If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com

 **spheria**[®]

