

# Assembly Instructions / 2 bases Panel Holder 13<sup>mm</sup>



**1**

Screw the stabilizer elements under the half spheres  
*with a flat screwdriver.*

**2**

Screw the 0,50 m tubes  $\varnothing 25$  mm into the half spheres,  
and screw the 1 m tubes  $\varnothing 20$  mm and the 0,50 m tubes  $\varnothing 20$  mm.

**3**

Slide the spheres  $\varnothing 20$  mm on the tubes, adjust them at the desired height  
and gently tighten.

**4**

Screw the black spheres.

**5**

Place the panel (not included) between the four spheres  
and gently tighten.



If you want the components to be locked,  
use the threadlocker sold on [www.e-spheria.com](http://www.e-spheria.com)

**S** p h e r i a<sup>®</sup>

