Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw the tube into the half sphere.

3

Screw the circular top on the tube.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



