

Assembly Instructions / Recto Verso Panel Holder



1

Screw two tubes
into the half spheres.

2

Slide the lower part of the visual
(not provided) on the tubes.

3

Screw two tubes.

4

Place the upper part of the visual on the tubes,
gently tighten.

Pull the lower part of the visual and gently tighten.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

S p h e r i a[®]

