

Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw the tube into the half sphere.

Slide the sphere ø25 mm with the kit on the tube at the desired height and oriented as you wish. Gently tighten.

Fix the lectern on the tube.





If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



