

Assembly Instructions / Panson



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw the $\varnothing 25$ mm tube into the half sphere.

3

Screw the 0,50 m tube.

4

Fix the horizontal bar with the Panson.
(Panel not provided).



If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com

Spheria®

