

Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw one tube ø25 mm into the half sphere,

and a tube ø25 mm into the first one and then the 0,50 m tube.

3

Slide the horizontal bar at the desired height

and gently tighten. Slide the visual (not included) on the bar.

4

Fix the black sphere.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



