

Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw a tube into the half sphere and a second tube into the first one.

3

Fix the black sphere.

4

Clip the four a4 frames on the tubes.

5

Place the black rubber ring on the clip at the back of each frame.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



