

1

Screw the stabilizer elements under the half spheres with a flat screwdriver.

2 Screw the ø25 mm tubes into the half spheres.

Slide the ø25 mm spheres with the horizontal bar on the tubes.

4 Screw the 0,50 m tubes.

Screw the ø20 mm spheres on the tubes and slide the horizontal aluminium bar, gently tighten.

6

Fix the brakets and the clips at the back of your frame

(not included) and place it on the horizontal bar.

Gently tighten.

Place the black rubber rings on the clips.

If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



