

Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw a tube into the half sphere

and a second tube into the first one.

3

Fix the triade sphere.

4

Place the top of the kakemono on the triade.

Clip the lower part of the kakemono on the tube.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



