

Screw the stabilizer elements under the half spheres

with a flat screwdriver.

Screw the tubes into the half spheres.

Fix the 4 directions ring and the black spheres on the tubes.

Place the rope.



If you want the components to be locked, use the threadlocker sold on www.e-spheria.com



