

# Assembly Instructions / Reception Desk



**1**

Screw the stabilizer elements under the half spheres  
*with a flat screwdriver.*

**2**

Screw the two tubes into the half spheres.

**3**

Slide the extension spheres on the tubes, gently tighten.  
*The small tightening buttons must  
be at the back of the bank.*

**4**

Fix the small fixing plates under the top of the desk  
*with a N°3 Allen key.*

**5**

Screw the tubes and the half spheres into the small fixing plates.

**6**

Install the panel (*not included*) and adjust it at the desired height.  
*Gently tighten.*



If you want the components to be locked,  
use the threadlocker sold on [www.e-spheria.com](http://www.e-spheria.com)

**S**pheria®

