

Assembly Instructions / Signage Block



1

Screw the stabilizer element under the half sphere

with a flat screwdriver.

2

Screw the tube into the half sphere.

3

Fix the triade.

4

Place the sign (not included) in the triade sphere.

Gently tighten with the button.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

Spheria®

