

Assembly Instructions / Coat Rack



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw a tube into the half sphere
and a second tube into the first one.

3

Slide the coloured pegs at the desired height
and oriented as you wish. Gently tighten.

4

Fix the black sphere.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

S p h e r i a[®]

