

Assembly Instructions / Compact laminate panel holder



1

Screw the stabilizer elements under the half spheres
with a flat screwdriver.

2

Screw the 0,50 m tubes $\varnothing 25$ mm into the half spheres
and screw the 1 m tubes $\varnothing 20$ mm and the 0,50 m tubes $\varnothing 20$ mm.

3

Slide the spheres $\varnothing 20$ mm on the tubes, adjust them at the desired height
and gently tighten.

4

Fix the black spheres.

5

Place the panel between the four spheres
and gently tighten.



If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com

 **spheria**[®]

