


Assembly Instructions / Capture sound totem –



1

Screw the stabilizer element under the half sphere
with a flat screwdriver.

2

Screw the 0,50 m tube $\varnothing 25$ mm into the half sphere
and screw the 1 m tube $\varnothing 20$ mm.

3

Slide the two spheres $\varnothing 20$ mm on the tubes,
adjust them at the desired height
and gently tighten.

4

Fix the black sphere.

5

Place the panel between the two spheres
and gently tighten.

6

Clip the screw cover.



If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com

 **spheria**[®]

