

Assembly Instructions / Panel Mitesco



Remove the central cap (part b)

with a flat screwdriver.

2

Place the front face of the panel

coloured edge = front face (a).

3

**Place the back of the part (b) with the black edge
and the front of the part (c) with the coloured edge.**

Clip them together.

4

**Fix the screws in the screw cover
and then fix them in the extension spheres.**

5

Fix the panels together.



*If you want the components to be locked,
use the threadlocker sold on www.e-spheria.com*

S p h e r i a[®]

